

Manufacturer

MEIKO Maschinenbau GmbH & Co. KG

Model no. M-iClean UM+

Product Description
Premium Undercounter Dish Washing Machine

Origin

Offenburg, Germany

SPECIFICATIONS		
Function	Premium undercounter dish washing machine The function of the dishwasher is to provide the mechanical action necessary to distribute and direct the detergent solution and rinse waters over, under and around the dishes to loosen and remove soil. The dishwasher must also remove soil-laden waters from the machine. This should be done with the lowest consumption of fresh water, energy and chemical products	
Form	Dimension : W 600 mm x D 600 (930) mm x H 820 mm Entry Height : 435mm Rack Size : 500 x 500mm	
Construction	 Heavy duty Double-wall construction with additional insulation and rear cladding as a standard stainless steel 304. Hose proof according to safety standard IP X5 Combined wash and rinse arm system made of stainless steel 304 to guarantee 100% coverage of entire wash tank Rounded stainless steel 304 wash tank completely covered with easily removable tank filter sieve M-iClean filter system to remove dirt and reduce detergent and water consumption for an excellent wash result Maintenance-friendly access to all aggregates stainless steel pipes for all supply lines Drain pump easily accessible from inside the machine Wash pump with dish & glass protecting soft start with water level monitoring Intelligent energy management system to gradually shift into standby mode, through a progressive series of power-saving modes Self-cleaning program, temperature display, electronic control system, Progress bar LED illuminated interior when door is open Ergonomic crystal glass touch display and LED Indicator handle Intelligent function monitoring with message display Bluetooth interface for service data 	

Engineering / MEP Ratings	 Voltage 400V/3NPE/50Hz or 230V/1NPE/50Hz Connecting Load: 6.7 kW (3NPE) or 2.7 (1NPE) Fuse protection: 16A Water pressure: min. 0.6 bar, max. 5 bar Drain hose DN22 Inlet ³/₄"
Capacity	 3 selectable speeds for 40/30/15 racks/hour expandable to 9 programmes (incl. customer-specific settings) Program cycle 90/120/240 sec Tank content: 11 litres
Sanitation	Entirely corresponds to the regulations of DIN SPEC 10534 for Commercial dishwashing with one-tank dishwashers and for commercial dishwashing with glass washing machines. - Wash tank 60°C – 65°C - Final rinse 80°C – 85°C
Accessories	 1 plastic universal basket VKV 50/1 (500 x 500mm) 1 small item basket VKV 50/2 BK Liquid detergent dosing unit Rinse aid dosing unit Connection kit Stainless steel rear cladding OPTIONAL: Reverse Osmosis GiO module (Socle / rear / separate) OPTIONAL: M-iClean AirConcept Heat recovery
Safety	- CE (European Standard) - EN 1717 - DIN SPEC 10534
Special Requirement	Water Hardness max. 3°dh or approx. 50 ppm

Rev01/150517